

# Viper Strike

## Manual

USER MANUAL  
**VIPERSTRIKE**  
GAMING CONTROLLER



### About the Wireless Controller

Before using this product, carefully read this manual and any manuals for compatible hardware.

**Retain instructions for future reference.**

### Product specification

Model: <b>VIPERSTRIKE</b>	Connection: BT 4.0
Compatible with: P4/PC/ANDROID/IOS	Cable Plug: USB-C
Working Current: 20 mA	Input Voltage: 5V
Continuous Use Time: >8 H	Input Current: 1A
Charging Time: About 3 H	Working Voltage: 3.7V
Package Size: 166 x 70 x 118 mm	Battery Capacity: 600 mAh

### Battery Life and Duration

Do not handle damaged or leaking lithium-ion batteries.

- The battery has a limited lifespan. Battery duration will gradually decrease with repeated usage and age.
- Battery life also varies depending on the storage method, conditions of use, and environmental factors.
- Charge in an environment where the temperature range is between 50°F-86°F (10°C-30°C). Charging may not be as effective in other environments.
- If the wireless controller is not used for an extended period of time, it is recommended that you fully charge it at least once a year to help maintain battery functionality.

### Use and Handling Precautions

1. Avoid prolonged use of this product. Take a break at about 30-minute intervals.
2. Permanent hearing loss may occur if the headset or headphones are used at high volume. Set the volume to a safe level. Over time, increasingly loud audio may start to sound normal but can actually be damaging your hearing. If you experience ringing or any discomfort in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the sooner your hearing could be affected. To protect your hearing:
  - Limit the amount of time you use the headset or headphones at high volume.
  - Avoid raising the volume to block out noisy surroundings.
  - Lower the volume if you can't hear people speaking near you.

3. Avoid looking into the light bar of the controller when it is flashing. Stop using the controller immediately if you experience any discomfort or pain in any body parts.
4. This product is intended for use with hands only.
5. The vibration function of this product may aggravate injuries. Do not use the vibration function if you have any ailment or injury to the bones, joints, or muscles of your hands or arms.
6. Note that some software titles enable the vibration function by default. To disable the vibration function, select [Settings]-> [Devices]-> [Controllers] from the function screen, and then remove the checkmark from [Enable Vibration].
7. Do not expose the product to high temperatures, high humidity, or direct sunlight.
8. Do not allow the product to come into contact with liquids.
9. Do not put heavy objects on the product.
10. Do not throw or drop the product or subject it to strong physical shock.
11. When using the motion sensor function, be cautious of the following points.
  - If the controller hits a person or objects, this may cause accidental injury or damage.
  - If the controller hits a person or objects, this may cause accidental injury or damage.
  - If using a controller that is connected to the PlayStation 4 system with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or objects. Also, take care to avoid pulling the cable out of the PS4 system while using the controller.

### Exterior protection

Follow the instructions below to help prevent the product exterior from deteriorating or becoming discolored.

- Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
- Use a soft, dry cloth to clean the product. Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.

### Registering (Pairing) the Controller

Console Connection:

- In the sleep state of the handle, use the USB data cable to connect the console to complete the pairing. Press the PS button to connect wirelessly, unplug the cable to control wirelessly (automatically match the LED).
- It has been successfully connected, no matter whether the PS4 host is sleeping, you can directly press the PS button, and the LED will flash slowly. Automatically connect back.

- Four handles can be used at the same time; the RGB lights will be in the order of blue, red, green, pink. Turn on the lights and configure each gamepad!

### PC Bluetooth Mode Connection

1. Press and hold SHARE+PS to enter pairing; the LED flashes quickly, search and connect the Wireless Controller. Enter the computer Bluetooth for pairing; if the pairing is successful, you can play computer games.
2. It has been successfully connected; you can directly press the HOME button, the LED will flash slowly in the form of a marquee, and it will automatically connect to the computer.

### Wired Connection Instructions

1. Console Connection:
  - Under the sleep state of the controller, use the USB cable to connect to the console.
  - After the connection is successful, the corresponding LED light is always on.
2. PC Wired Connection
  - Under the sleep state of the controller, use the USB cable to connect to the host to complete the pairing. (It is recommended to play games on the steam platform).