


Hornet Fury Elite

Manual

USER MANUAL


HORNETFURY ELITE

GAMING CONTROLLER




Thank you for choosing the Hornet Fury Elite Wireless Gamepad. Please read the manual carefully before use and keep it in a safe place. The instruction manual you have been compiled with the latest information. All screen shots and graphic diagrams in its content have been prepared with the aim of introducing the gamepad in your hand with direct methods. Due to technical reasons and R&D studies, there may be different between the screenshots and graphics mentioned and shown in the manual.


Packages includes



Gamepad





User Manual



Type C

Joystick Panel Features



Product Description

The Hornet Fury Elite controller is Bluetooth controller for PS4 console, PC, Android and IOS system devices., the Bluetooth connection distance of the controller reaches more than 10M.

The back part has 2 customized keys, which can be matched with the desired function keys.

There is a 3.5 mm jack input that can be connected to headset and microphone to receive and transmit sound at the same time. Built-in speaker

With a Type-C port for charging the controller.


With two Hall 3D joysticks


With two analog triggers

Built-in 1200mAh Lion polymer battery


Connect to PS4 Console

You need to use Type-C cable to communicate with the PS4 console for this first time.

The program automatically performs the code pairing during the communication process. Press  button, gamepad can be connected to wireless communication via Bluetooth.



When USB cable is connected to the console, press the  button, the LED light shows a single color is always on. It means connected to the console successfully.

When different gamepads are connected console, the LED light shows different colors to distinguish different users.



It can use most 4 gamepads to connect console and play games at the same time. If already paired and that have not been cleared after connecting to console, press the  button to wake up the dormant console.

Connect to PC




The gamepad is connected to the PC through the data cable to support the X_INPUT function, computer will automatically install the driver, device displays the name of Xbox 360 Controller For Windows, to realize the Xbox 360 gamepad function.

The gamepad can be connected to PC via Bluetooth. Open the Bluetooth settings, select Add Device and press the  button and  button of the joystick at the same time, the joystick indicator will flash to enter the pairing status, and "Wireless Controller" will appear in the Bluetooth in your computer, after clicking on it, the computer will automatically pair with the joystick and connect to it and install the driver automatically.

Connect to Smartphone

The gamepad can be connected to the smartphone through Bluetooth. Open smartphone Bluetooth settings, press gamepad's  key and  key at the same time, gamepad indicator will flash fast to enter the pairing state, smartphone searches and appear Bluetooth name "Wireless Controller", click on phone will automatically be paired with the gamepad to connect, and automatically install the driver, support Android and IOS system devices.



M1-M2 Customized key restores default no function







































Place gamepad in sleeping state on a flat desk, press and hold the  and  keys, then press the  key and release it till the red light blinks, after about 5 seconds the red light will go out and the two customized keys will be restored to a non-functional state.

LED Charging Indicator

When gamepad is sleeping and charging, the RGB indicator will be displayed as a breathing light with orange color, and indicator will be off when it is full.

Customized Function Key Settings

When the joystick is connected to the PS4 console or PC, press and hold the  key and M1 (or M2) key, and then release it to enter the M1 key customization state, the  indicator is on blue.

Then short press function keys [e.g. , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , , ,